





SPAR Racking Pty Ltd | Unit 10 / 16 Loyalty Road | North Rocks | NSW 2151
 02 96309194 | sales@spar-racking.com.au | www.spar-racking.com.au

Frame Bracing Arrangement – 2000, and 2200mm frames



*When using the Caster Baseplate bracing position will move 50mm to the next hole position

Frame Bracing Arrangement – 2500, and 3000mm frames



*When using the Caster Baseplate bracing position will move 50mm to the next hole position

